



**NOTE:**

CUT A CROSS THE SIZE OF THE PIPE IN THE CENTER OF A SQUARE PIECE OF GEOTEXTILE FABRIC, WHICH WILL CREATE FLAPS. SLIDE THE FLAPS OVER THE END OF PIPE. STUFF THE ENDS OF THE PIECE OF FABRIC INTO THE FABRIC THAT SURROUNDS THE TANK STRUCTURE, WITH THE FLAPS PULLED OUT AROUND THE PIPE. USE ZIP TIES AND/OR TAPE TO SECURE THE FLAPS TO THE PIPE.

## ECOVOID™ HD PIPE COLLAR CONCEPTUAL DESIGN USING GEOTEXTILE FABRIC